

IN THE UNITED STATES PATENT AND TRADEMARK OFFICE

In re application of: Peters et al

Serial No.: 09/238,851

Examiner: Webb, G.

Filed: 1/27/99

Art Unit: 1751

Docket No.: 5545A

Title: Low Surface Tension, Low Viscosity, Aqueous, Acidic Compositions Containing Fluoride And Organic Polar Solvents For Removal Of Photoresist And Inorganic Etch Residues At Room Temperature

DECLARATION OF R. ROVITO UNDER 37 C.F.R. §1.132

I, Roberto Rovito, declare as follows:

1. I currently am employed by Ashland Specialty Chemical Company, a division of Ashland Inc., as a Senior Applications Engineer where I have worked since February 1, 1999.
2. I was awarded a Bachelor of Science in Chemistry and Mathematics in 1978 from Marietta College in Ohio and a PhD. in Organic Chemistry in 1985 from Temple University in Pennsylvania. I held a post-Doctoral post from 1985-1987 at Stanford University in California.
3. Among my responsibilities are the development of new products and testing of existing products in the semiconductor cleaning area.
4. All of the formulations listed in Exhibit 1 were prepared and titrated in Ashland's laboratory facilities in Easton, Pennsylvania. Formulations labeled as Examples 1-5 correspond to examples 1-5 in US Patent No. 5,972,862. Examples DP-1 and DP-2 are identical except acetic acid was added to DP-2. ACT is an example of a buffered composition within the scope of the claims of the presently claimed invention. Pages 1-2

of Exhibit 1 show calculations for creating one type of buffered solution. Page 3 contains the formulations for various examples. Pages 4-13 are titration curves for the various formulations.

5. I have reviewed the contents of Exhibit 1. The results show the difference between a buffered composition (ACT) and compositions (Examples 1-5, DP1 and DP2) that do not function as buffers. Buffered solutions are those solutions that are capable of maintaining their pH at some fairly constant value even when small amounts of acid or base are added. In general, the effective range for a given buffer is about one pH unit on either side of the pK_a of the acid being used. The most effective buffer, ie., the buffer having the greatest pH range on either side of the pK_a for a given acid is prepared using a 1:1 ratio of protonated and deprotonated forms of a weak acid. An example of such a buffer is the ACT example in Exhibit 1. Simply adding an acid and its conjugate base to a formulation does not create a solution that will function as a buffer. Examples 1-5 from patent 5,972,862 show how formulations that contain both an acid and a base fail to provide a buffered system, ie the formulations cannot maintain a fairly constant pH when small amounts of a base is added. In contrast a buffered composition of the present invention "ACT" maintains a fairly constant pH up to about the addition of 10 ml of 0.1N KOH. It was postulated in a rejection of the present invention that the addition of acetic acid to a composition containing ammonium fluoride would form a buffered solution in situ. Examples DP-1 and DP-2 show that merely adding a weak acid to a formulation does not create a solution able to with stand the addition of small amounts of 0.1N KOH.

6. I hereby declare that all statements made herein of my own knowledge are true and that all statements made on information and belief are believed to be true; and further that these statements were made with the knowledge that willful false statements and the like so made are punishable by fine or imprisonment, or both under Section 1001 of Title 18 of the United States Code and that such willful false statements may jeopardize the validity of the application or any patent issued thereon.

Date:

July 15, 2003

Roberto Rovito

Roberto Rovito

0307sdec312

EXHIBIT 1

Technical description of a buffered solution

Formulations for examples 1-5, DP-1, DP-2 and ACT

Titration curves for the formulations

Using a Weak Acid to Create a Buffered Solution

For a weak acid: $\text{HA} \rightleftharpoons \text{H}^+ + \text{A}^-$, and the equilibrium constant is k_a

where $k_a \equiv [\text{H}^+][\text{A}^-]/[\text{HA}]$

$$\log k_a = \log [\text{H}^+] + \log [\text{A}^-] - \log [\text{HA}]$$

$$-\log k_a = -\log [\text{H}^+] - \log [\text{A}^-] + \log [\text{HA}]$$

$$-\log k_a \equiv \text{p}k_a$$

$$-\log [\text{H}^+] \equiv \text{pH}$$

$$\text{hence, } \text{p}k_a = \text{pH} - \log [\text{A}^-] + \log [\text{HA}]$$

$$\text{and } \text{pH} = \text{p}k_a + \log [\text{A}^-] - \log [\text{HA}]$$

$$\text{or } \text{pH} = \text{p}k_a + \log ([\text{A}^-]/[\text{HA}])$$

if $[\text{A}^-]/[\text{HA}]$ is < 1 , then $\text{pH} < \text{p}k_a$

if $[\text{A}^-]/[\text{HA}] = 1$, then $\text{pH} = \text{p}k_a$

if $[\text{A}^-]/[\text{HA}]$ is > 1 , then $\text{pH} > \text{p}k_a$

EXAMPLE #1

Propionic Acid	1.00
Amm. Fl. Anhydr.	8.00
Dimethyl Formamide	40.00
TMAF 25%	20.00
EP-120A	0.10
DI Water	30.90
pH = 5.04	

EXAMPLE #2

Phthalic Anhydride	0.10
Amm. Fl. Anhydr.	8.00
TMAF 25%	20.00
EP-120A	0.10
DI Water	31.80
Formamide	40.00
pH = 5.42	

EXAMPLE #3

Isobutyric Acid	0.20
Amm. Fl. Anhydr.	5.00
DMAC	35.00
TMAF 25%	40.00
EP-120A	0.10
DI Water	19.70
pH = 5.42	

EXAMPLE #4

Acetic Acid	0.10
Amm. Fl. Anhydr.	10.00
Dimethyl Formamide	45.00
TMBC	3.00
EP-120A	0.10
pH = 5.45	

EXAMPLE #5

Amm. Fl. Anhydr.	1.00
Dimethyl Formamide	69.00
DI Water	29.00
Boric Acid	0.30

DP1

DMAC	67.5
DI Water	30.0
NH4F (40%)	2.5
Acetic Acid (glac.)	0.0

DP2


DMAC	65.5
DI Water	30.0
NH4F (40%)	2.5
Acetic Acid (glac.)	2.0

ACT

DMAC	57.5
Ammonium Acetate	15.6
Acetic Acid (glac.)	12.0
DI Water	12.4
Amm. Floride (40%)	2.5
pH = 4.75	


DMAC - Dimethylacetamide
TMAF - Tetramethylammonium formate
TMBF - Tetramethylammonium acetate
EP-120A - Is a poly(oxyethylene)phenylester from Dai-ichi Kogyo Seiyaku Co., Ltd.

Titration Curves for Various Formulations



EX #1(011598)
pH/ml

pH




'fr
751 GPD Titrimo 09140 751.0020 titant/0.1% KOH
date 2001-03-21 time 10:38 215
card label:Appl.751
pH(init) 4.61 DET pH NE14PA
smpl size 0.5061 id#1 EX #1
EP1 1.220 ml 6.69
stop #EP reached
device label Titrimo sign:JE

'mp
751 GPD Titrimo 09140 751.0020
date 2001-03-21 time 10:38 215
pH(init) 4.61 DET pH NE14PA
smpl size 0.5061 id#1 EX #1

V/ml	pH	T/°C	ERC
0.0000	4.615		0.0
0.0500	4.637		13.2
0.1000	4.665		16.1
0.1500	4.693		18.3
0.5120	4.940		23.4
0.8000	5.231		31.5
0.9440	5.454		40.7
1.0380	5.662		51.1
1.1180	5.931		60.6
1.1800	6.314		65.9
1.2320	6.806		66.9
1.2840	7.238		63.7
1.3440	7.484		55.7
1.3940	7.620		44.9
1.5380	7.876		34.5
1.7240	8.079		0.0
1.9740	8.262		0.0


pH



'fr
751 GPD Titrimo 09140 751.0020
date 2001-03-21 time 10:43 216
card label:Appl.751
pH(init) 5.05 DET pH NE14PA
smpl size 0.5713 id#1 EX #2
EP1 0.328 ml 6.55
stop #EP reached
device label Titrimo sign:JE

titrant: 0.1N KOH

'mp
751 GPD Titrimo 09140 751.0020
date 2001-03-21 time 10:43 216
pH(init) 5.05 DET pH NE14PA
smpl size 0.5713 id#1 EX #2
V/ml pH T/°C ERC
0.0000 5.055 0.0
0.0500 5.118 34.1
0.1000 5.209 44.0
0.1500 5.337 53.5
0.2240 5.596 63.2
0.2900 6.082 68.3
0.3420 6.728 68.9
0.3920 7.198 65.4
0.4440 7.416 56.9
0.4940 7.560 45.8
0.6320 7.809 35.0
0.8160 8.011 0.0
1.0660 8.195 0.0




'fr
 751 GPD Titrimo 09140 751.0020
 date 2001-03-21 time 10:48 217
 card label:Appl.751
 pH(init) 5.12 DET pH NE14PA
 smpl size 0.5739 id#1 EX #3
 EP1 0.350 ml 6.75
 stop #EP reached
 device label Titrimo sign: JE

titrant: 0.1N KOH


'mp
 751 GPD Titrimo 09140 751.0020
 date 2001-03-21 time 10:48 217
 pH(init) 5.12 DET pH NE14PA
 smpl size 0.5739 id#1 EX #3

V/ml	pH	T/°C	ERC
0.0000	5.121		0.0
0.0500	5.178		33.1
0.1000	5.270		43.2
0.1500	5.388		52.9
0.2420	5.714		63.1
0.3040	6.151		68.8
0.3560	6.832		70.1
0.4060	7.444		67.2
0.4680	7.712		58.1
0.5180	7.842		44.6
0.6660	8.099		33.9
0.8540	8.301		0.0
1.1060	8.489		0.0



```
'fr
751 GPD Titrimo      09140  751.0020
date 2001-03-21      time 10:54    218
card label:Appl.751
pH(init)      5.13      DET pH      NE14PA
smpl size     0.5613      id#1      EX #4
EP1           0.450 ml      6.74
stop #EP reached
device label   Titrimo      sign: JB
```

```
'mp
751 GPD Titrimo      09140  751.0020
date 2001-03-21      time 10:54    218
pH(init)      5.13      DET pH      NE14PA
smpl size     0.5613      id#1      EX #4
V/ml          pH      T/°C      ERC
0.0000        5.131      0.0
0.0500        5.179      28.2
0.1000        5.253      36.3
0.1500        5.339      44.5
0.2960        5.684      56.2
0.3780        6.061      65.0
0.4320        6.539      68.2
0.4820        7.116      67.0
0.5340        7.414      60.8
0.5840        7.579      49.7
0.7140        7.843      38.0
0.8860        8.060      27.5
1.1160        8.246      0.0
1.4160        8.415      0.0
```



'fr
 751 GPD Titrimo 09140 751.0020
 date 2001-03-21 time 13:21 222
 card label:Appl.751
 pH(init) 4.55 DET pH NE14PA
 smpl size 1.3935 id#1 EX #5
 EP1 0.297 ml 6.58
 stop #EP reached
 device label Titrimo sign: SE


~~titrant~~
 0.1N KOH

'mp
 751 GPD Titrimo 09140 751.0020
 date 2001-03-21 time 13:21 222
 pH(init) 4.55 DET pH NE14PA
 smpl size 1.3935 id#1 EX #5

V/ml	pH	T/°C	ERC
0.0000	4.543		0.0
0.0500	4.618		40.7
0.1000	4.743		52.4
0.1500	4.924		62.0
0.2120	5.302		69.1
0.2640	5.936		72.4
0.3140	6.920		72.7
0.3640	7.679		69.4
0.4140	7.898		59.7
0.4640	8.030		45.0
0.6100	8.289		34.6
0.7960	8.496		0.0
1.0440	8.693		0.0

DP1(011603)
pH/ml


pH



'fr
751 GPD Titrimo 09140 751.0020
date 2001-03-21 time 11:06 220
card label:Appl.751
pH(init) 5.70 DET pH NE14PA
smpl size 0.5318 id#1 DP1
EP1 1.432 ml 10.22
stop #EP reached
device label Titrimo sign:JE

titrant: 0.1N KOH

'mp
751 GPD Titrimo 09140 751.0020
date 2001-03-21 time 11:06 220
pH(init) 5.70 DET pH NE14PA
smpl size 0.5318 id#1 DP1
V/ml pH T/°C ERC
0.0000 5.519 0.0
0.0500 6.328 73.8
0.1000 7.780 73.3
0.1500 8.243 67.8
0.2000 8.407 53.3
0.3300 8.689 40.7
0.4940 8.940 33.7
0.6980 9.193 30.7
0.9300 9.472 31.3
1.1660 9.791 33.7
1.3860 10.146 34.6
1.5300 10.372 32.2
1.7280 10.619 27.1
1.8660 10.741 21.2
2.1500 10.931 16.0
2.4840 11.083 11.7
2.8920 11.213 0.0
3.3740 11.330 0.0




'fr
751 GPD Titrimo 09140 751.0020
date 2001-03-21 time 11:12 221
card label:Appl.751
pH(init) 4.01 DET pH NE14PA
smpl size 0.554 id#1 DP2
EP1 1.728 ml 7.12
stop #EP reached
device label Titrimo sign:JE

titrant: 0.1N KOH

'mp
751 GPD Titrimo 09140 751.0020
date 2001-03-21 time 11:12 221
pH(init) 4.01 DET pH NE14PA
smpl size 0.554 id#1 DP2

V/ml	pH	T/°C	ERC
0.0000	4.013		0.0
0.0500	4.046		18.7
0.1000	4.087		22.6
0.1500	4.133		23.4
0.4000	4.356		23.2
0.6780	4.598		23.5
0.9640	4.854		26.0
1.2460	5.147		32.6
1.4640	5.478		43.2
1.5660	5.739		54.8
1.6300	6.004		65.0
1.6860	6.433		70.3
1.7380	7.277		71.3
1.7880	7.945		68.4
1.8400	8.188		59.9
1.8900	8.338		48.2
2.0260	8.628		39.4
2.1920	8.867		0.0
2.4040	9.109		0.0



'mp 751 GPD Titrimo 09140 751.0020
 date 2001-02-16 JE time 10:39 80
 pH(init) 4.79 DET pH NE14
 smpl size 10.5549 in id#1 NE-14
 ~60ml H2O pH T/°C ERC
 0.0000 4.792 0.0
 0.0500 4.793 1.7
 0.1000 4.795 2.4
 0.1500 4.799 2.6
 0.8100 4.847 2.6
 1.5260 4.901 2.6
 2.2560 4.961 2.6
 2.9740 5.018 2.7
 3.6980 5.081 2.8
 4.4080 5.144 2.9
 5.1160 5.209 3.1
 5.8200 5.280 3.4
 6.5100 5.360 3.8
 7.1760 5.442 4.3
 7.8360 5.541 5.0
 8.4520 5.645 5.9
 9.0540 5.772 7.4
 9.5940 5.910 10.1
 10.0980 6.110 14.2
 10.4200 6.293 20.4
 10.6780 6.514 28.7
 10.8420 6.744 37.3
 10.9360 6.930 43.8
 11.0240 7.158 46.8
 11.1060 7.382 45.5
 11.2400 7.685 40.0
 11.3360 7.833 32.1
 11.5380 8.052 24.3
 11.7900 8.237 17.9
 12.1060 8.400 13.4
 12.4900 8.549 10.3

titrant used: 0.1N KOH

12.9320	8.678	8.3
13.4320	8.803	6.9
13.9640	8.911	6.0
14.5360	9.013	5.4
15.1340	9.114	4.9
15.7420	9.205	4.6
16.3700	9.292	4.4
17.0120	9.382	4.3
17.6520	9.470	4.3
18.2940	9.557	4.3
18.9400	9.644	4.5
19.5860	9.743	0.0
20.0000	9.809	0.0

=====